



Note: most seat part #'s reflect the seat type, style & dimensions of the seat.
 I.e. seat part # SV201820RB =
Seat Vinyl 20"wide x 18"deep x 20"high
 (not including head rest), Reclining, Black.
Legend: S=Seat, V=Vinyl, R=Reclining,
 G=Grey, B=Black, P=Pan seat.

Powerchair Seat Chart

POWERCHAIRS	MODEL NAME & STANDARD SEAT SIZE	UPGRADE SEATS	ADDITIONAL UPGRADE SEATS	NOTES
	Jimmie UL8PBS SV18171/219G	SP161618RG	SF171613G	 Refer to model Jimmie UL8PB for Fish-on (Stadium) seat.
	Smartie UL8W SV18171/219G	N/A	N/A	Due to lightweight features, the seat cannot be changed from the O.E. seat.
	Streamer Sport 888WA SV191821B	SV171/21815G SV171/21714RB SV18171/219G SV2121211/2RB SV2121211/2RG	SF181614G SF191714G(K) SP161618RG SP181821RG SP202023RG	 Seat pan seats do not include seat cushion.
	6Runner 10 Deluxe 858WM SV191820RG	SV18171/219G SV201820RB SV2121211/2RG SV2121211/2RB	SP161618RG SP181821RG SP202023RG SPREHAB18B(K)	 Seat pan seats do not include seat cushion.
	6Runner 10 888WNLM-RED SV201820RB	SV18171/219G SV191820RG SV201820RB SV2121211/2RG SV232020B	SP161618RG SP181821RG SP202023RG SPREHAB18B(K)	 Seat pan seats do not include seat cushion.

	<p>6Runner14 888WNLL HD SV2121211/2RG</p>	<p>SV18171/219G SV191820RG SV201820RB SV2121211/2RB SV221922RG SV232020B</p>	<p>SP161618RG SP181821RG SP202023RG</p>	 <p>Seat pan seats do not include seat cushion.</p>
---	---	--	---	--